

Lovibond® Water Testing Tintometer® Group



CE 2000 Pt-Co

Colour measurement of water



- Immediate & Accurate
- Straight from the Box
- Guaranteed Agreement with International Standards
- Display Results with On-Screen Colour and Numerical Options

Artigo No: 162010

Dual Ability to View Colour Comparison

- On-screen colour
- On-screen numerical display

Easy Transition from Visual to Electronic Measurements

Some colour graders who are used to the traditional comparator series sometimes find the upgrade to an electronic system daunting. The assurance of relying on physical colour difference is diminished. This transition has now been made easy.

Touch Screen Technology

Enables you to easily programme the instruments with instinctive menus on screen.

Programmable Settings

You can set language*, date and time, view preferences and create projects with individual tolerance settings.

On-Screen Warning System

You can react immediately to results that might be out of tolerance with immediate information on the sample.

- Within tolerance = green
- Outside tolerance = red
- On border of tolerance = amber

User Friendly Ergonomics and Intuitive Interface

You are guaranteed to be up and running quickly and easily supported.

Easy storage and sharing of results

Large data storage (> 20,000 readings) and USB connectivity ensure your results can be stored and easily shared.

Single Scale Measurement

The EC 2000 Pt Co provides you an individual scale to measure Platinum Cobalt/Hazen/Apha Colour (ASTM D 1209).

* Supported languages: English, French, German, Spanish, Italian, Chinese, Japanese, Russian.

Indústria

Indústria de Alimentos e Bebidas | Indústria Farmacêutica | Indústria Química | Óleo e Gás

Aplicação

Farmacêuticos e Cosméticos | Óleos e Gorduras Comestíveis | Óleos e Graxas de Petróleo | Químicos

CE 2000 Pt-Co

Advance from visual (subjective) to electronic (objective) colour measurement.

High precision with 50 mm cuvette path length!

Dados Técnicos

Tipo de Cor	Transparent
Display	Tamanho: 3.5 polegadas; resolução: 320 x 240; Cor: 24 Bit (Cor verdadeira)
Interfaces	USB
Armazenamento Interno	> 20000 medições
Fonte de Alimentação	USB 2.0 (conector mini USB) 4 pilhas (AA)
Teclado	Membrana de teclado com 3 teclas
Gabinete do Equipamento	ABS retardador de chama
Portabilidade	Portátil
Tela Sensível ao Toque	Não
Idiomas da Interface do Usuário	Alemão, Inglês, Francês, Espanhol, Italiano, Russo, Chinês, Japonês
Dimensões	106 x 57 x 210 mm

Texto do Escopo de Entrega

- Instrument in carrying case
- Power Supply (UK, EU, US Plug)
- USB Cable
- 4 AA Batteries
- Liquid Reference Standard 1
- Liquid Reference Standard 2
- Glass cuvette
- Glass standard
- CD with Software (Windows®)
- Instruction Manual

Título	Artigo No
Padrão líquido Cobalto platina número de cor 0 - 500 ml	133991
Padrão líquido Platinum-cobalto número de cor 15 - 500 ml	134160
Padrão líquido Cobalto platina número de cor 30 - 500 ml	134170
Padrão líquido Cobalto platina número de cor 15 - 60 ml	135049
Padrão líquido Cobalto platina número de cor 0 - 60 ml	135059
10001723	190620
Cabo USB 2.0 A - Conector Micro B	190630
Cuvetes de plástico descartáveis de 50 mm	352101

Tintometer GmbH

Lovibond® Water Testing
Schleefstraße 8-12
44287 Dortmund
Tel.: +49 (0)231/94510-0
sales@lovibond.com
www.lovibond.com
Alemanha

The Tintometer Limited

Lovibond House
Sun Rise Way
Amesbury, SP4 7GR
Tel.: +44 (0)1980 664800
Fax: +44 (0)1980 625412
sales@lovibond.uk
www.lovibond.com
Reino Unido

Tintometer China

9F, SOHO II C.
No.9 Guanghualu,
Chaoyang District,
Beijing, 100020
Customer Care China Tel.: 4009021628
Tel.: +86 10 85251111 Ext. 330
Fax: +86 10 85251001
chinaoffice@tintometer.com
www.lovibond.com
China

Tintometer South East Asia

Unit B-3-12, BBT One Boulevard,
Lebuh Nilam 2, Bandar Bukit Tinggi,
Klang, 41200, Selangor D.E
Tel.: +60 (0)3 3325 2285/6
Fax: +60 (0)3 3325 2287
lovibond.asia@tintometer.com
www.lovibond.com
Malásia

Tintometer Brazil

Caixa Postal: 271
CEP: 13201-970
Jundiaí – SP
Tel.: +55 (11) 3230-6410
sales@lovibond.us
www.lovibond.com.br
Brasil

Tintometer Inc.

6456 Parkland Drive
Sarasota, FL 34243
Tel: 941.756.6410
Fax: 941.727.9654
sales@lovibond.us
www.lovibond.us
EUA

Tintometer India Pvt. Ltd.

Door No: 7-2-C-14, 2nd, 3rd & 4th Floor
Sanathnagar Industrial Estate,
Hyderabad, 500018
Telangana
Tel: +91 (0) 40 23883300
Toll Free: 1 800 599 3891/ 3892
indiaoffice@lovibond.in
www.lovibondwater.in
Índia

Tintometer Spain

Postbox: 24047
08080 Barcelona
Tel.: +34 661 606 770
sales@tintometer.es
www.lovibond.com
Espanha

Technical changes without notice

Printed in Germany

Lovibond® and Tintometer® are Trademarks of the Tintometer Group of Companies